


Gibson / Epiphone Les Paul Wiring Diagram



⏏ = Ground