



Telecaster SH 3 Way Switch Wiring Diagram



 =Ground