



Fender Telecaster, 4 Way Switch Left Handed Wiring Diagram 250k Reverse Pots



 =Ground