

Fender Telecaster Left Handed with 3 Way Toggle Switch Wiring Diagram

250k Reverse Taper

