


## Fender Telecaster Reverse Left Handed 3 Way Switch Wiring Diagram 250k Reverse Taper Pots



Ground Wire from Bridge

⏏ = Ground